

How to Use the SunCard



Predict the position of the sunrise or sunset for each month of the year.

A valuable tool for the serious landscape photographer, film maker, garden designer or architect.

Simply point the card towards north or overlay it on your map (the card is transparent) and the card tells you where the sun will rise and set for each month of the year. It is accurate to within 5 degrees.

A handy credit card size, fits in your wallet so you can take it anywhere. The card is waterproof and virtually scratch proof. Postage is FREE worldwide.

There is a Northern and Southern version of the Card. The Northern Version (covers 45-55 degrees latitude) suitable for Northern Europe, Northern US and Southern Canada. The Southern version (covers 35-45 degrees latitude) suitable for Southern Europe and most of the US.

Mark Kidd

www.suncard.co.uk